

SONIDO SPEAKER SIZES

		d1	d2	d3	h1	h2	h3
SFR	145	145	124	90	70	43	6
SFR	145/A	145	124	62	76	43	6
SFR	175	175	149	102	76	48	6
SFR	175/A	175	149	82	99	48	6
SFR	200	200	168	112	80	48	7
SFR	200/A	200	168	82	98	48	7
SWR	200	200	168	104	79	48	7
SWR	200/A	200	168	82	98	48	7
SWR	250	250	228	112	92	64	8
SWR	300	300	268	112	118	90	8
SCW	300	300	268	112	118	90	8
SCW	400	385	349	184	168	146	11

